



**100% COMPATIBLE  
WITH HEXIS FILMS**

# BODYWORK SHAMPOO

ProTech® Concentrated Bodywork Shampoo is specially formulated to destroy the static film and restore the gleam to your filmed surfaces. It can be apply to all films and leaves no trace.



## INSTRUCTIONS FOR USE

- Add two capfuls of ProTech® Bodywork Shampoo per litre of water.
- Allow 3 litres of the preparation in a bucket to wash a vehicle.
- Rinse the car with a jet of water before applying the shampoo.
- Apply ProTech® Bodywork Shampoo to the whole vehicle (bodywork, windows, plastic) using a soft sponge.
- Rinse copiously with a jet before the product dries.
- Do not wash a car in full sun. Do not apply to very hot surfaces.

## TIPS

Apply any special products (tar, insect remover etc.) before shampooing. Always begin a complete wash at the top of the vehicle. Wash the lowest, dirtiest surfaces last. Rinse the sponge thoroughly. Product neutral pH, ideal for matt filmed surfaces.