



TECHNICAL DATA SHEET - PROTECTIVE FILM **BODYXFAST**

BODYXFAST is a transparent, ultra-flexible, adhesive-coated film, which is self-healing at ambient temperature and specially developed for quicker and easier film application. Its excellent shock-absorbing properties protect your bodywork against chips caused by stones, car doors, washing brushes, insects, etc. Glossy surface finish.

FILM FEATURES:

	<u>Indicative value</u>	
• Total thickness (film + adhesive) (µm):	180 (7.1 mil) ±10 %	
	<u>Average values</u>	<u>Standard</u>
• Tensile strength (N/25 mm):	> 40	HEXNFX41021
• Elongation at break (%):	> 200	HEXNFX41021
• Shrinkage 168 hours at 70 °C (158 °F) (mm):	< 0.2	HEXRET001

LINER:

- Silicone-coated PET liner.

ADHESIVE PROPERTIES:

(Measured average values at publication of the technical data sheet)

	<u>Average values</u>	<u>Standard</u>
• Peel strength test 180° (N/25 mm):		HEXFTM001
after 20 minutes of application:	12	
after 24 hours of application:	13	
• Initial tack (N/25 mm):	10	HEXFTM009
• Release (N/25 mm):	0.1	HEXFTM003

ADHESIVE:

- Solvent-based, acrylic adhesive.
- Immediate and permanent adhesion, optimal after 24 hours of contact.

USER'S INSTRUCTIONS:

- The BODYXFAST film is intended for vehicle car body protection. It can also serve as a protection system for full-wrap films (HX20000, non-structured HX30000 and HX30SCH00) used for smooth and basic full-wraps without relief decoration.

The application of BODYXFAST to full-wrap films is at the customer's judgement. HEXIS recommend the use of pre-cut BODYXFAST for this particular application. As the adhesion of BODYXFAST is permanent, its removal from a full-wrap film can damage the latter. HEXIS decline any responsibility in the case of deterioration of a full-wrap film caused by the application and removal of BODYXFAST.

- Self-healing properties of the film at ambient temperatures: This phenomenon of reabsorbing scratches accelerates especially as the temperature increases.
- Recommended minimum application temperature: +10 °C (+50 °F). Apply preferably between +15 °C and +35 °C (+59 °F and +95 °F).
- Operating temperature range: -40 °C à +90 °C (-40 °F to +194 °F).
- Cut the film to the size of the part to be wrapped, allowing +10 cm (4 in.) of extra margin.

The remaining film must be stored on its original core (do not cut the rolls into several lengths or widths, do not repackage the product); the roll must be closed immediately and properly (masking tape or roll-collars) after use in order to preserve all its qualities.

- Apply wet.
- Apply to a surface that is clean and free from any traces of contaminants (dust, grease, wax, silicone, etc.).

Particular care must be taken to clean the angles and periphery of the target surfaces in order to enable the film to adhere properly to the surface.

- In the case of an already painted substrate, self-adhesive media must only be applied to undamaged original paintwork. If the paintwork is not original and/or damaged, the application and the removal are at the judgement and risk of the installer.

OPERATING RECOMMENDATIONS:

- Conformable product developed for protecting bodywork, underbody, painted bumpers and rear-view mirror casings against chips caused by stones, insects and scratches.
- Excellent protection against vandalism (key scratches).
- To facilitate application, HEXIS have several types of squeegees in their range of accessories, ranging from softer to harder (plastic or felt).
- For more information on the application method of BODYXFAST, please refer to the Application Guide on the "Professionals" pages, category "Solar and safety films" on our site www.hexis-graphics.com.

STORAGE:

- Shelf life (before application):

The shelf life of this film is 1 year when stored upright in its original packaging in a dust-free environment at a temperature ranging from +15 °C to +25 °C (+59 °F to +77 °F) with a relative humidity of 50 %.

DURABILITY:

- The film's lifespan depends on the type of substrate, its preparation, exposure conditions and frequency of the cleaning.

For instance, it is estimated that a south-facing exposure will divide the durability by two. The same applies to a horizontal exposure. In addition, elevated temperatures (above +50 °C) (+122 °F) or pollution significantly reduce this durability.

- Vertical exposure, Central European climate:
Up to 10 years (under normal road use conditions).

Applied to a full-wrap film with a durability of less than 10 years, BODYXFAST will increase the durability against yellowing and cracking of the full-wrap film by up to 1 year (within the limit of the BODYXFAST durability).

To find the indicative durabilities of the films for any other exposure and geographical area, please refer to the "Conversion rules for indicative durabilities according to geographical area" chart available under Durability, on the "Professionals" pages on our site www.hexis-graphics.com.

NOTES:

Due to the great variety of substrates and the growing number of new applications, the installer must check the suitability of the medium for each application. In case of doubt, request an expert evaluation of the compatibility of the film and the glass in question. All of the published information is based on measurements regularly performed in the laboratory. The published information does not however constitute a binding guarantee. The seller cannot be held liable for indirectly related damages and assumes no liability for claims that are higher than the replacement value of the purchased product. All specifications are subject to potential changes without prior notice. Our specifications are automatically updated on our website www.hexis-graphics.com.