



TECHNICAL DATA SHEET - DIGITAL PRINTING - LAMINATE - PERMANENT ADHESIVE PC190G2 - PC190M3

Film composed of a 50- μ m, clear, cast PVC, which is coated with a pressure-sensitive acrylic adhesive. Glossy (PC190G2) or matt (PC190M3) surface finish; for cold laminating cast HEXIS digital printing films: films of the 100 series and HX190WG2. This laminate, which is thicker than the current 30- μ m laminates, enables the compound to be easier handled and installed.

FILM FEATURES:

| | | Indicative value | |
|---|---|------------------|-----------------|
| • | Thickness (µm): | 50 | |
| | | Average values | <u>Standard</u> |
| • | Tensile strength (N/25 mm): | min. 30 | HEXNFX41031 |
| • | Elongation at break (%): | min. 100 | HEXNFX41031 |
| • | Shrinkage 168 hours at 70 °C (158 °F) (mm): | < 0.5 | HEXRET001 |
| • | UV absorption (%): | > 90 | NF EN 410 |

LINER:

- Silicone-coated PE paper 145 g/m², with grey "THE CAST by HEXIS" print.
- Stable under hygrometric variations.

ADHESIVE PROPERTIES:

(Measured average values at publication of the technical data sheet)

| | | Average values | <u>Standard</u> |
|---|--|----------------|-----------------|
| • | Peel strength test 180° on glass (N/25 | mm): | HEXFTM001 |
| | after 20 minutes of application | 16 | |
| | after 24 hours of application | 20 | |
| • | Initial tack (N/25 mm): | 20 | HEXFTM009 |
| • | Release (N/25 mm): | 0.3 | HEXFTM003 |

Resistance to solvents: the adhesive is resistant to most chemicals (alcohol, diluted acids, oils).

ADHESIVE:

- Solvent-based acrylic adhesive.
- Immediate and permanent adhesion.

USER'S INSTRUCTIONS:

- Protection of solvent inkjet printed cast films.
- Recommended minimum application temperature: +10 °C (+50 °F).
- Operating temperature range: from -40 °C to +90 °C (-40 °F to +194 °F).
- For film cleaning, only use a non-abrasive sponge or soft cloth and soapy water.
- UV protection.
- In the case of an already painted substrate, self-adhesive media must only be applied to undamaged original paintwork. If the paintwork is not original and/or damaged, the application and the removal are at the judgement and risk of the installer.

OPERATING RECOMMENDATIONS:

 Prior to any lamination, coating or other of a cast printed film, you have to wait for 48 hours after printing in order to ensure optimal drying time for the inks.

STORAGE:

Shelf life (before application):

The shelf life of this film is I year when stored upright in its original packaging in a dust-free environment at a temperature ranging from +15 °C to +25 °C (+59 °F to +77 °F) with relative humidity of 50 %.

DURABILITY: (Central European climate)

Vertical outdoor exposure:


Without mechanical stress: up to 5* years.

With mechanical stress: depends on the type and frequency of the stresses.

*Time during which the film retains a correct surface finish, from a conventional viewing distance. (A slight and gradual change in colour and gloss is natural and is an inevitable and natural phenomenon inherent in the natural breakdown of the materials).

Note: The durability indicated in this document:


- concerns only the laminate and not the finished visual or graphic.
- is inherent to an upright position of ± 10° and to the product's geographical exposure position. All other positions accentuate the climatic shocks and promote the appearance of an alteration of the gloss or even a slight dusting. Southern exposure, with a 45° inclination can divide the durability of the film by 2, and horizontal exposure by 2.8. Application to the vehicle bonnet is particularly severe, due to the horizontal exposure and the heating provided by the engine.





up to 7 years (for surfaces or areas not subject to frequent handling or high visitor frequency).

A film applied to surfaces exposed to mechanical stress will be subject to repeated abrasion that will reduce more or less rapidly its lifespan (change of appearance, peeling off, etc.).



NOTES:

Due to the great variety of substrates and the growing number of new applications, the installer must check the suitability of the medium for each application.

The measuring methods for the standards quoted above served as the basis for the development of our own measuring methods which are available on request. Please feel free to contact us to get the latest instructions in use.

All the published information is based on measurements regularly performed in the laboratory. It does not however constitute a binding guarantee. The seller cannot be held liable for indirectly related damages and assumes no liability for claims that are higher than the replacement value of the purchased product. All specifications are subject to potential changes without prior notice. Our specifications are automatically updated on our website www.hexis-graphics.com.