



Looking for a high-quality printable film that is easy to apply for installations on 2D surfaces?

HEXIS have developed **THE200EVO**, the next generation of digital printing films, for people just like you.

Easy repositioning and print quality along with optimal durability make it suitable for use in any circumstances and applications: wrapping of flat or slightly curved surfaces, 2D wraps [e.g. vehicle fleets, lorries, buses, food trucks], large-format signs and more.

THE200EVO can be used with the new **V850B** laminate, but also with the **V750**, **PC500** or **VCR750**.

ECO-S

SOLV

LATEX

UV

**TAKE
HEAT
EASY** 

GRAPHICS DIVISION



LOW INITIAL TACK / REPOSITIONABLE PRINTABLE POLYMERIC FILM

Enjoy the benefits of THE200EVO

TAKE HEAT EASY® [THE] technology is the result of combining a new solvent-based adhesive with a new structured liner. This HEXIS innovation has been specifically developed to provide a low initial tack and make the film easy to apply.

The new **THE200EVO** combines all the benefits of **TAKE HEAT EASY®** [THE] technology with the technical performance of a premium, printable polymeric film.

There is no better way to save time during installation whilst achieving quality results, making it a perfect solution for any 2D large-format projects, particularly those that require fast and accurate positioning of printed graphics.

Choose the right laminate

Protect your prints with the new **V850B** [50 µm] laminate, designed for THE200EVO. It will help you achieve a particularly flexible complex.

These laminates can also be used: **V750** [70 µm] for solids that require less flexibility, **VCR750** [70 µm] for printing with UV inks, or the 100% PVC-free laminate **PC500** [50 µm] for higher UV resistance.

www.hexis-graphics.com/en/produit/the200evo/



Product specifications

White gloss printable film

- > **Polymeric**, calendered PVC
- > Permanent, solvent-based acrylic adhesive
Grey adhesive face with **TAKE HEAT EASY® micro-structure**
- > **70 µm** thickness
- > Indoor and outdoor applications
- > Compatible inks: **ECO-S** **SOLV** **LATEX** **UV**
- > Durability / Unprinted film: **8 years** for outdoor use [vertical exposure]
- > Available in 1370 and 1600 mm x 45 m [other retail options are possible, depending on stock availability]

**TAKE
HEAT
EASY** 

GRAPHICS DIVISION

STREET FOOD MAKER

HEXIS