Architectural Window Film

Data Sheet



SolarZone™ Interior Matte™ 2 mil, Black Out™, White Out™, UV Filter™ Film 2 mil

Introduction

Matte white films give a translucent sandblasted effect, adding privacy or designer elegance to doors, windows and room dividers. Black or White Out films are ideal for hiding views or for disguising features that spoil the external appearance of glass-fronted buildings. UV Filter Film provides a very good level of protection from UV radiation, both UV-A and UV-B rays without altering the clarity of the glass.

Typical Usage

- Ideal for enhancing the functionality and appearance of glass
- All speciality films are popular for indoor applications in the areas of:
- Residential & Commercial
- Museum & Retail

Product Construction

Face: Matte 2 mil, Black Out, White Out, UV Filter

Adhesive: Pressure sensitive permanent - solvent based acrylic

Liner: PET

Certificates

Fire Certificate:

- Matte 2 mil, UV Filter: DIN EN 13501-1: 2010 B-s1, d0



Shelf Life and storage conditions:

When stored in original packaging upon arrival at the customer: 2 years. Recommended Storage conditions are 20 °C (\pm 2 °C) with 50 %RH (\pm 5%).

Key Features

- Matte white films provide a translucent sandblasted effect, adding privacy or designer elegance
- Privacy films are ideal for hiding unattractive views

Film Performance

Warranted Durability in Years:

	Matte Translucent 2 mil	Black Out	White Out	UV Filter 2 mil
Durability	12	5	5	12



Optical & Solar Properties

Glazing Unit: Pane Single Clear 3mm	Matte Translucent 2 mil	Black Out	White Out	UV Filter 2 mil
Visible Light Transmitted %	72	0	10	87
Visible Light Reflected - Interior %	-	-	-	-
Visible Light Reflected - Exterior %	17	6	48	11
UV Block %	94	100	99	100
Total Solar Energy Reflected %	14	41	36	9
Total Solar Energy Transmitted %	68	0	17	79
Total Solar Energy Absorbed %	18	59	47	12
Emissivity (Room Side)	0.90	0.72	0.90	0.86
Glare Reduction %	20	100	89	3
Selective InfraRed Reduction %	33	99	98	21
InfraRed Energy Reduction %	26	91	62	17
Shading Coefficient	0.84	0.20	0.37	0.95
Solar Heat Gain Coefficient (G-Value)	0.73	0.16	0.31	0.82
U-Value Winter (IP)	1.07	0.98	1.07	1.05
U-Value Winter (SI)	6.08	5.57	6.08	5.96
Luminous Efficacy	0.86	0	0.27	0.92
Total Solar Energy Rejected	27	84	69	18



Important notice Information on physical and chemical characteristics and values in this document are based upon tests we believe to be reliable and do not constitute a warranty. They are intended only as a source of information and are given without guarantee and do not constitute a warranty. Purchasers should independently determine, prior to use, the suitability of this material to their specific use. All technical data are subject to change. In case of any ambiguities or differences between the English and foreign versions of this document, the English version shall be prevailing and leading.

Disclaimer and warranty Avery Dennison warrants that its Products meet its specifications. Avery Dennison gives no other express or implied guarantees or warranties with respect to the Products, including, but not limited to, any implied warranties of merchantability, fitness for any particular use and/or non infringement. All Avery Dennison products are sold with the understanding that the purchaser has independently determined the suitability of such products for its purposes. The period of warranty is one (1) year from the date of shipment unless expressly provided otherwise in the product data sheet. All Avery Dennison's products are sold subject to Avery Dennison's general terms and conditions of sale, see http://terms.europe.averydennison.com. Avery Dennison's aggregate liability to Purchaser, whether for negligence, breach of contract, misrepresentation or otherwise, shall in no circumstances exceed the price of the defective, non-conforming, damaged or undelivered Products which give rise to such liability as determined by net price invoices to Purchaser in respect of any occurrence or series of occurrences. In no circumstances shall Avery Dennison be liable to Purchaser for any indirect, incidental or consequential loss, damage or injury, including without limitation, loss of anticipated profits, goodwill, reputation, or losses or expenses resulting from third party claims.