



TECHNICAL DATA SHEET - PLOTTER VINYLs - BLOCK OUT WHITE or BLACK BLOCK OUT FILM

Range comprising of a 165- μ m, polymeric, colaminated PVC, which is coated with a pressure-sensitive, acrylic adhesive. Matt surface finish. Colour of the adhesive-coated side: black for the BOBLANC, white for the BONOIR film.

FILM FEATURES:

	<u>Indicative value</u>	
• Thickness (μ m):	165	
	<u>Average values</u>	<u>Standard</u>
• Tensile Strength (N/25 mm):	min. 70	HEXNFX41021
• Elongation at break (%):	min. 180	HEXNFX41021
• Shrinkage (mm)	< 0.4	HEXRET001

LINER:

- Silicone-coated Kraft paper 137 g/m², with grey HEXIS print.
- Stable under hygrometric variations.

ADHESIVE PROPERTIES:

(Measured average values at publication of the technical data sheet)

	<u>Average values</u>	<u>Standard</u>
• Peel strength test 180° on glass (N/25 mm):		HEXFMTM001
after 20 minutes of application	19	
after 24 hours of application	24	
• Initial tack (N/25 mm):	18	HEXFMTM009
• Release (N/25 mm):	0.2	HEXFMTM003
• Resistance to solvents: the adhesive is resistant to most chemicals (alcohol, petrol, diluted acids, oils, fuels).		

ADHESIVE:

- Solvent-based, acrylic adhesive.
- Immediate and permanent adhesion; suitable for wet application.

USER'S INSTRUCTIONS:

- Recommended minimum application temperature: +10 °C (+50 °F).
- Operating temperature range: -40 °C to +90 °C (-40 °F to +194 °F).
- In the case of painted substrates, self-adhesive media must only be applied to undamaged original paintwork. If the paintwork is not original and/or damaged, the application and the removal are at the judgement and risk of the installer.

STORAGE:

- Shelf life (before application):

The shelf life of this film is 2 years when stored in its unopened original packaging at a temperature ranging from 15 °C to 25 °C (+59 °F to +77 °F) with relative humidity between 30 % and 70 %.

DURABILITY: (Central European climate)

- Application in vertical exposure: 5 years.

To find the indicative durabilities of the films for any other exposure and geographical area, please refer to the "Conversion rules for indicative durabilities according to the geographical area" chart available under Durability, on the "Professionals" pages on our site www.hexis-graphics.com.

NOTES:

Due to the great variety of substrates and the growing number of new applications, the installer must check the suitability of the medium for each application. The measuring methods for the standards quoted above served as the basis for the development of our own measuring methods, which are available on request. Please feel free to contact us to get the latest instructions in use. All of the published information is based on measurements regularly performed in the laboratory. The published information does not however constitute a binding guarantee. The seller cannot be held liable for indirectly related damages and assumes no liability for claims that are higher than the replacement value of the purchased product. All specifications are subject to potential changes without prior notice. Our specifications are automatically updated on our website www.hexis-graphics.com.