## **Architectural Window Film**

Data Sheet



SolarZone™ Interior OptiTune™ 05, 15, 22, 30, 40

#### Introduction

The SolarZone Dual Reflective product lines - OptiTune and Titan<sup>™</sup> - combine a reflective outer layer for high solar energy rejection with a less reflective inner layer to preserve the view outside and maintain indoor ambience. All films deliver high levels of protection from solar heat. The films cut costs by reducing the need for air conditioning and boosting energy efficiency - a sustainable solution.

# Typical Usage

• For interior applications - OptiTune combines high solar energy rejection with low internal reflectance. Its warm neutral grey tone targets both residential and commercial use.

### **Product Construction**

Face: OptiTune 05, 15, 22, 30, 40

Adhesive: Pressure sensitive solvent based

Liner: PET

#### Certificates

Fire Certificate: DIN EN 13501-1: 2010 B-s1, d0

# Shelf Life and storage conditions:



When stored in original packaging upon arrival at the customer: 2 years. Recommended Storage conditions are 20 °C (± 2 °C) with 50 %RH (± 5%).

# **Key Features**

- OptiTune neutral grey films are available with water activated adhesive
- OptiTune is available in a wide range of Visible Light Transmissions, ("VLT") in a subtle neutral grey appearance, with a highly effective heat rejecting semi-reflective exterior, and a subtle interior.

## Film Performance

Warranted Durability in Years:

	OptiTune 05	OptiTune 15	OptiTune 22	OptiTune 30	OptiTune 40
Durability	12	12	12	12	12



# Optical & Solar Properties

Glazing Unit: Pane Single Clear 3mm	OptiTune 05	OptiTune 15	OptiTune 22	OptiTune 30	OptiTune 40
Visible Light Transmitted %	6	13	21	32	41
Visible Light Reflected - Interior %	15	25	15	26	18
Visible Light Reflected - Exterior %	63	56	32	32	21
UV Block %	99	99	99	99	99
Total Solar Energy Reflected %	56	51	31	32	22
Total Solar Energy Transmitted %	6	12	18	25	33
Total Solar Energy Absorbed %	38	37	51	43	45
Emissivity (Room Side)	0.75	0.76	0.80	0.81	0.83
Glare Reduction %	93	85	77	63	54
Selective InfraRed Reduction %	94	88	83	79	71
InfraRed Energy Reduction %	82	77	68	65	57
Shading Coefficient	0.19	0.26	0.38	0.44	0.54
Solar Heat Gain Coefficient (G-Value)	0.16	0.22	0.33	0.37	0.46
U-Value Winter (IP)	0.99	1.00	1.02	1.03	1.04
U-Value Winter (SI)	5.62	5.68	5.79	5.85	5.91
Luminous Efficacy	0.32	0.50	0.55	0.75	0.76
Total Solar Energy Rejected	84	78	67	63	54



**Important notice** Information on physical and chemical characteristics and values in this document are based upon tests we believe to be reliable and do not constitute a warranty. They are intended only as a source of information and are given without guarantee and do not constitute a warranty. Purchasers should independently determine, prior to use, the suitability of this material to their specific use. All technical data are subject to change. In case of any ambiguities or differences between the English and foreign versions of this document, the English version shall be prevailing and leading.

Disclaimer and warranty Avery Dennison warrants that its Products meet its specifications. Avery Dennison gives no other express or implied guarantees or warranties with respect to the Products, including, but not limited to, any implied warranties of merchantability, fitness for any particular use and/or non infringement. All Avery Dennison products are sold with the understanding that the purchaser has independently determined the suitability of such products for its purposes. The period of warranty is one (1) year from the date of shipment unless expressly provided otherwise in the product data sheet. All Avery Dennison's products are sold subject to Avery Dennison's general terms and conditions of sale, see http://terms.europe.averydennison.com. Avery Dennison's aggregate liability to Purchaser, whether for negligence, breach of contract, misrepresentation or otherwise, shall in no circumstances exceed the price of the defective, non-conforming, damaged or undelivered Products which give rise to such liability as determined by net price invoices to Purchaser in respect of any occurrence or series of occurrences. In no circumstances shall Avery Dennison be liable to Purchaser for any indirect, incidental or consequential loss, damage or injury, including without limitation, loss of anticipated profits, goodwill, reputation, or losses or expenses resulting from third party claims.