



TECHNICAL DATA SHEET – LAMINATE WITH GLITTER EFFECT – PERMANENT ADHESIVE

PCSTARXX Series

Range of products comprising of a 70-µm, clear, cast PVC with glitter effect, which is coated with a pressure-sensitive acrylic adhesive. Glossy or satin surface finish; intended for cold laminating.

FILM FEATURES:

Inc	licati	VA.	บวไเ	ıΔ
1110	ııcau	V C	٧aiv	ac.

Thickness (µm): 70

Average values Standard

Tensile strength (N/25 mm): min. 20 HEXNFX41031

• Elongation at break (%): min. 100 HEXNFX41031

• Shrinkage 168 hours at 70 °C (158 °F) (mm): < 0.5 HEXRET001

LINER:

- Silicone-coated PET liner 75 μm.
- Stable under hygrometric variations.

ADHESIVE PROPERTIES:

(Measured average values at publication of the technical data sheet)

		Average values	<u>Standard</u>
•	Peel strength test 180° on glass (N/25 m after 20 minutes of application after 24 hours of application	m): 21 25	HEXFTM001
•	Initial tack (N/25 mm):	16	HEXFTM009
•	Release (N/25 mm):	0.3	HEXFTM003

ADHESIVE:

- Solvent-based acrylic adhesive.
- Immediate and permanent adhesion.
- Resistance to solvents: the adhesive is resistant to most chemicals (alcohol, diluted acids, oils).

USER'S INSTRUCTIONS:

- UV protection.
- For modifying/improving/protecting:
 - o a plotter or wrap vinyl: apply the PCSTARXXX film to unstructured films only using a cold laminator or via direct application. The compound can be cut using a plotter, except Super Chrome films (see technical data sheets of Super Chrome films). After cutting, it is possible to transfer with the HEX904 and HEX860 tapes.
 - a digital printing film: apply the PCSTARXXX film to solvent, eco-solvent, latex or UV inkjet printed films.
 - an already painted substrate: apply to undamaged original paintwork only. If the paintwork is not original and/or damaged, the application and the removal are at the judgement and risk of the installer.
- Recommended minimum application temperature: +10 °C (+50 °F).
- Operating temperature range: -40 °C to +90 °C (-40 °F to +194 °F).
- To clean the film, only use a non-abrasive sponge or soft cloth with soapy water.

OPERATING RECOMMENDATIONS:

- Before applying this laminate to a HEXIS digital printing film, which has been printed with solvent inks, it is recommended to respect the following optimal drying time for the inks:
 - 48 hours if the printed film is cast,
 - 24 hours if the printed film is calendered.

STORAGE:

• Shelf life (before application):

The shelf life of this film is I year when stored upright in its original packaging in a dust-free environment at a temperature ranging from +15 °C to +25 °C (+59 °F to +77 °F) with relative humidity of 50 %.

DURABILITY: (Central European climate)

Vertical outdoor exposure, upon substrate:

Without mechanical stress: up to 5* years.


With mechanical stress: depends on the type and frequency of the stresses.

*Time during which the film retains a correct surface finish, from a conventional viewing distance. (A slight and gradual change in colour and gloss is a natural and inevitable phenomenon inherent in the natural breakdown of the materials).

Note: The durability indicated in this document:

- concerns only the laminate and not the finished visual or graphic.

- is inherent to an upright position of ± 10° and to the product's geographical exposure position. Any other position accentuates climatic influences and an alteration in gloss or colour, or even a slight dusting may appear. Southern exposure, with a 45° inclination may divide the durability of the film by 2, and horizontal exposure by 2.8. Application to the vehicle bonnet is particularly severe, due to the horizontal exposure and the heat from the engine.
- is confirmed by UV ageing tests and vertical natural outdoor weathering.



• Indoor exposure, upon substrate: up to 7 years.

This durability may vary depending on frequency and type of cleaning / mechanical stress (friction, impacts etc.) to which the film is exposed.

To find the indicative durabilities of the films for any other exposure and geographical area, please refer to the "Conversion rules for indicative durabilities according to geographical area" chart available under Durability, on the "Professionals" pages on our site www.hexis-graphics.com.

NOTES

Due to the great variety of substrates and the growing number of new applications, the installer must check the suitability of the medium for each application.

The measuring methods for the standards quoted above served as the basis for the development of our own measuring methods, which are available on request. Please feel free to contact us to get the latest instructions in use.

All of the published information is based on measurements regularly performed in the laboratory. The published information does not however constitute a binding guarantee. The seller cannot be held liable for indirectly related damages and assumes no liability for claims that are higher than the replacement value of the purchased product. All specifications are subject to potential changes without prior notice. Our specifications are automatically updated on our website www.hexis-graphics.com.